

## Instrucciones de uso para sujeta cacerolas

### ESPECIFICACIONES

Tamaño total	Peso	Material
205 x 205 x 160 mm	190 g	Hierro/ PVC (ventosas)

### INSTRUCCIONES DE USO

1. Ponga el sujeta cacerolas en la vitrocerámica alrededor de la fuente de calor.
2. Presiona las tres ventosas hacia abajo y asegúrate de que el producto esté bien adherido.
3. Coloque el mango de la olla o cacerola en la ranura central.
4. Después de cocinar déjelo enfriar por unos minutos.

### ADVERTENCIA

- Las ventosas deben estar pegadas en una superficie plana y lisa.
- Asegúrese de que las tres ventosas se peguen firmemente a la superficie y estén al menos 5 cm alejado de la llama o la fuente de calor (mientras más lejos mejor).
- No deje el soporte junto a una llama o fuente de calor sin una olla o sartén.
- El soporte se calentará hasta cierto punto mientras se cocina. No toque el soporte mientras esté cocinando hasta haberse enfriado después de que se apague la fuente de calor.
- Inspeccione periódicamente el desgaste y los daños.

### MANTENIMIENTO

El marco de alambre debe ser limpiado con un paño. Las ventosas sólo se pueden limpiar a mano con agua fría.



## User Instruction for Pot/Pan Handle Holder

### SPECIFICATION

Overall Size	Weight	Material
205 x 205 x 160 mm	190 g	Iron / PVC(suction pads)

### INSTRUCTIONS FOR USE

1. Put the Pot/Pan Handle Holder around the corner of the stove.
2. Press the three suckers down and make sure the suckers are all stuck firmly.
3. Place the handle of the pot/pan in the center groove.
4. After cooking, please leave it cool naturally for a certain minutes.

### WARNING

- The suction pads should be stuck on a flat and smooth surface.
- Please ensure that the three suction pads are stuck firmly to the surface of the stove at least 5cm away from the flame or heat source (further away if possible).
- Do not leave the holder next to a naked flame or heat source without a pot or pan on it.
- The holder will heat up to a certain extent while cooking. Allow the holder to remain on the stove without touching it, until it has cooled down. Heat will remain in the holder after the heat source is turned off.
- Periodically inspect for wear and damage.

### MAINTENANCE

The wire frame should be wiped clean with a cloth.

The suckers can only be cleaned by hand wash with cold water.



